


Single door cabinets require hinging - default is Left
 Accessible cabinets are 32 1/2" high X 24" deep and have a 5 1/2" X 3" toe kick unless otherwise specified
 Handicap cabinets are 32 1/2" high X 24" deep and have a 9" X 6" toe kick unless otherwise specified

Accessible / Handicap All Door Blind Base Cabinets

AVAILABLE OPTIONS ARE SHADED																						
AF	BBD	BO	CFG	FAS	FC	FE	FF	FTK	IT	MD/ MD9	MI	NODR	NTK	PLYB	PLYE	RTB	SCD	SCH	SLB	TOT	XS	XX



Base filler shown (not included)
 *left shown

Accessible

ARBBAD36
 ARBBAD39
 ARBBAD42
 ARBBAD45
 ARBBAD48

Handicap


HARBBAD36
 HARBBAD39
 HARBBAD42
 HARBBAD45
 HARBBAD48

NOTES:

- No Shelf
- N/A in Full Overlay door styles
- Must be ordered left or right
- The RBB will need to be pulled away from the adjoining wall to clear adjoining cabinet, knobs and/or pulls used. The RBB will also need to be pulled if an appliance on the adjacent wall projects more than the 24" deep and is within 24" of the RBB. The "maximum" pull dimensions indicate the furthest distance the RBB can be pulled away from the adjacent wall - Pull information found in Introduction section
- **Filler not included, must order separately**

Accessible / Handicap All Door Blind Base Cabinets w/Lazy Susan

AVAILABLE OPTIONS ARE SHADED																						
AF	BBD	BO	CFG	FAS	FC	FE	FF	FTK	IT	MD/ MD9	MI	NODR	NTK	PLYB	PLYE	RTB	SCD	SCH	SLB	TOT	XS	XX



NOTES:

- N/A in Full Overlay door styles
- Door hinged from blind panel
- Regular LS comes with plastic trays, .W LS comes with wood trays
- Special depth is available increased only
- Two, half circle shelves rotate and pull out individually for added access
- N/A in Full Overlay door styles
- with wood shelves
- **Filler not included, must order separately**

Accessible

ARBBAD42LS
 ARBBAD45LS
 ARBBAD48LS

Handicap

HARBBAD42LS
 HARBBAD45LS
 HARBBAD48LS

Wood Trays

Accessible
 ARBBAD42LS.W
 ARBBAD45LS.W
 ARBBAD48LS.W

Wood Trays

Handicap
 HARBBAD42LS.W
 HARBBAD45LS.W
 HARBBAD48LS.W